

RUSSELL ARENA CLOCK INSTRUCTIONS

Start by powering up the NEVCO by turning on the switch on the bottom right. It will display 'Hockey' after 30 seconds.

- Press SET TIME – Enter Minutes (10), Seconds (00), Milli Seconds (0)
- RMHA Games are stop time games - 10 minutes 1st period, 10 minutes 2nd period, 12 minutes 3rd period.
- Press PERIOD BUTTON - Enter period number

To ENTER A GOAL or PENALTY

- Press HOME SCORE or GUEST SCORE, then add 1 then press TIME BUTTON to go back to having the time displayed on NEVCO
- To EDIT THE SCORE press SET, then HOME SCORE or GUEST SCORE and enter desired score number
- To set a PENALTY press NEW MINOR (on either the HOME or GUEST side), then enter TWO DIGITS for PLAYER NUMBER. Then enter the penalty time 02:00.
- To CLEAR a PENALTY press VIEW PENALTY (on either the HOME or GUEST side). Then press CLEAR PENALTY. Then press the TIME BUTTON to go back to time display on NEVCO.
- To EDIT A PENALTY press VIEW PENALTY (on either the HOME or GUEST side). Then press EDIT PENALTY, then enter TWO DIGITS for the PLAYER NUMBER and then enter the edited time for the penalty.
- If more than one penalty is entered you can scroll through penalties by pressing VIEW PENALTY until it displays the one you want to clear or edit.

Once SCORE or PENALTY has been set, press the TIME BUTTON if you want to see time displayed on NEVCO

***IF (possibly WHEN) the main score board goes blank, the wireless signal will automatically re-connect without losing track of the time or goals.

KEEP CALM AND HOCKEY ON

October 2017
Written by Ron Lachance